

1. Drill a 16 mm (0.63") diameter hole and two holes for the self-tapping screws in the duct at the intended location (see dimensioned drawing).
2. Unscrew the two screws of the housing cover and remove the cover.
3. Lead the connection cable through the cable gland into the unit and connect it to the terminals according to the electrical diagram.
4. Align the duct flange concentrically to the bore hole and fasten it to the duct with the self-tapping screws.
5. Insert the Condair CD or CDA-S through the duct flange into the bore hole in the duct. Determine the insertion depth and fix it with the screw in the duct flange.
Important: The measuring opening in the sensor pipe must point in the direction of the air.

